





User Menu Parameters		
Oled	Parametri	Editable
	Temperature Boiler	118°C - 123°C
°C °F	Unit of measurement	°C or °F
 	Water supply	Network or Tanica
 	Eco mode	ON or OFF

User Programming Input		
1	Press the middle button for 5 sec	
2	Scroll down to modify parameters	
3	Select the parameter to be modified	
4	Scroll the value to be modified	
5	Confirm with middle button	
6	Hold down the 5sec middle button to exit the programming and save the set data	

Parameters of the Technical Menu		
Oled	Parametri	Editable
	Temperature Group	60°C - 100°C
	Electrical test	OFF or ON
	Brightness Led	1 - 4
	Sensitivity Boiler	Low, Medium and High
	Sensitivity Tanica	Low, Medium and High

Technical Programming Input		
1	Press the key sequentially: Right, Left and finally the Central for 10 sec	
2	Scroll down to modify parameters	
3	Select the parameter to be modified	
4	Scroll the value to be modified	
5	Confirm with middle button	
6	Hold down the 5sec middle button to exit the programming and save the set data	

Factory Reset Product		
1	Switch off the machine	
2	Press and hold the middle button then turn on the machine	
4	Wait more than 10 seconds until the Reset icon appears. 	
5	Press the Left or Right button to change the icon from "OFF" to "ON"	
6	Set the Reset icon to "ON" and confirm with the middle button	
Switch off and on the machine		